

Quick Install / Setup with Lynx EVO Smart Cam

- **Uninstall** all previous version of Dimension One software, if any.
- Insert the **security dongle** into a USB port and wait until the 'Device driver software installed Successfully' message is displayed before continuing.
- **Install** Dimension One software by clicking "**DimensionOnev1.00.04Setup.exe**"
 - Follow On Screen Instructions – When finished **Reboot PC**
- **uEye Software Quick Setup**
- Install uEye Cockpit Software from provided usb drive - uEye64_46000_WHQL.exe
(Do not connect the Lynx EVO to the computer)
- **Connect** the Lynx EVO Smart CAM to the PC and **power it ON**
(Lynx EVO Camera name in Device Mgr - UI-155xLE)
- Launch uEye Cockpit.- Select "**Optimal Color**" or "**No Profile**"
(Select Expert mode if you need dimensioning or image annotation)



- Click on the '**Open camera**' icon to activate Lynx EVO SmartCam HD.



- Load Camera Settings Parameters from the USB thumb drive:
 - **Go to File / Load parameters / from File....select USB drive**
 - Open folder **uEye Cockpit software** and select
"LynxEvoSmartcamHD_CameraSettings_1v2 (APR17).ini"
- **Adjust settings** as needed to create the optimal image for your subject.
- **Save Camera Settings**
 - **Go to File / Save Parameters / To file option**
 - Save the Settings file to ...
C:\Users\Public\Documents\MetLogix\Settings folder
 - The file name **MUST** be renamed and saved as "**DimensionOne-1.ini**"
- **Close uEye Software**
- Insert the **D1 Dongle** in to the USB port on PC
- **Open** the Dimension One software
- Set up Supervisor Password and Language as needed.
- **Video Setup**
 - Click on the **D1** icon in the top right of the screen
 - Go to **Settings** and then **Video**
 - Select Image Source as "**uEye**"
 - Camera Choice as "UI-155xLExxxxx"
 - Click **Done x 2 and CLOSE** the Software
 - **Restart** Dimension One Software
- Dimension One is now installed and **ready for use**.