

Quick Install / Setup with Lynx EVO Smart Cam5

- **Uninstall** all previous versions of Dimension One/Two software if any.
- Insert the **security dongle** into a USB port and wait until the 'Device driver software installed Successfully' message is displayed before continuing. (Only displayed if those drivers are missing)
- **Install** Dimension Two software by clicking "**D2v1.20.00Setup.exe**"
 - Follow On-Screen Instructions – When finished **Reboot PC**

uEye Software Quick Setup

- Install uEye Cockpit Software from the provided USB drive - uEye64_46000_WHQL.exe
(Do not connect the Lynx EVO to the computer)
- **Connect** the Lynx EVO Smart CAM5 to the PC and **power it ON**
(Lynx EVO Camera name in Device Mgr - **U358xLE-C 4xxxxxxx**)
- Launch uEye Cockpit.- Select "**Optimal Color**" or "**No Profile**"
(Select Expert mode if you need dimensioning or image annotation)



- Click on the '**Open camera**' icon to activate Lynx EVO SmartCam HD.



- Load Camera Settings Parameters from the USB thumb drive:
 - **Go to File / Load parameters / from File....select USB drive**
 - Open folder **uEye Cockpit software** and select
“**LynxEvoSmartCam5_CameraSettings_1v0 (APR17).ini**”
- **Adjust settings** as needed to create the optimal image for your subject.
- **Save Camera Settings**
 - **Go to File / Save Parameters / To file option**
 - Save the Settings file to ...
C:\Users\Public\Documents\MetLogix\Settings folder
 - The file name **MUST** be renamed and saved as “**DimensionTwo-1.ini**”
- **Close uEye Software**
- Insert the **D2 Dongle** into the USB port on the PC
- **Open** the Dimension Two software
- **Video Setup**
 - Click on the **D2** icon in the top right of the screen
 - Go to **Settings** and then **Video**
 - Select Image Source as “**uEye**”
 - Camera Choice as “**U358xLE-C 4xxxxxxxx**”
 - Choose “Config File” settings as “**1**”
 - Click **Done x 2** and **CLOSE** the Software
 - **Restart** Dimension One Software
- Dimension Two is now installed and **ready for use**.