

## Quick Install / Setup with EVO CAM II

- Make sure the **Firmware** on EVO CAM II is 2.00.5 or higher
- **Uninstall** all previous version of Dimension One software, if any.
- Insert the **security dongle** into a USB port and wait until the 'Device driver software installed Successfully' message is displayed before continuing.
- **Install** Dimension One software by clicking "**DimensionOnev1.00.04Setup.exe**"
  - Follow On Screen Instructions – When finished **Reboot PC**
- **Connect** EVO CAM II **DIRECT** in to PC/Laptop via **USB3** cable port on back
  - **Power ON** EVO CAM II
- Insert the **D1 Dongle** in to the USB port on PC
- **Open** the Dimension One software
- Set up Supervisor Password and Language as needed.
- **Video Setup**
  - Click on the **D1** icon in the top right of the screen
  - Go to **Settings** and then **Video**
  - Select Image Source as "**DirectShow**"
  - Camera Choice as "**EVOCam2**"
  - Click **Done x 2 and CLOSE** the Software
  - **Restart** Dimension One Software
- Dimension One is now installed and **ready for use**.