

Quick Install / Setup with EVO CAM II

- Make sure the **Firmware** on EVO CAM II is 2.00.9 (REV:1.0.0.40:02.00.9:01.06 or higher)
- **Uninstall** all previous version of Dimension Two software if any
- Insert the **security dongle** into a USB port and wait until the 'Device driver software installed Successfully' message is displayed before continuing.
- **Install** Dimension Two software by clicking "**D2v1.20.00Setup.exe**"
 - Follow On Screen Instructions – When finished **Reboot PC**
- **Transfer preset** Magnification and Calibrations files to settings
 - **Go to** C:\Program Files (x86)\DimensionTwo\D2 Configuration Files
 - Double click "**Transfer D2 Configuration Files.bat**" file
 - When prompted press **any button** on keyboard to continue
 - DO NOT open the D2 software yet.
- **Connect** EVO CAM II **DIRECT** in to PC/Laptop via USB3
 - Turn ON EVO CAM II
 - Get the COM Port # from the device manager
- Add COM Port # to "**MetlogixD2.ini**" file
 - **Go to** C:\Users\Public\Documents\MetLogix\Settings
 - **Open** "MetLogixD2.ini" file in Notepad
 - **Delete Semicolon** " ; "
 - **Add** the COM port number
 - **Save and Close** the file

[EvoCam]

```
;Port=3 //Sets the Com(Serial) port for the connected EvoCamII hardware.
```

- Insert the **D2 Dongle** and open the software
- Click on the **D²** icon in the top right of the screen, go to **Settings** and then **Video**
 - Select Image Source as "**DirectShow**"
 - Camera Choice as "**EVOCam2**"
 - Click **Done x 2 and Close** the Software
- Dimension Two is now installed and **ready for use**.