

## Quick Install - Lynx EVO SmartCam 50

### Min. Recommended Computer Specs:

Windows 10 (32/64-bit) / Intel® Core i5 - 2.5 GHz / 4GB RAM / 200 GB HD / USB 3.0 ports

1. **Uninstall** all previous versions of Dimension One/Two software if any.
2. Insert the **security dongle** into a USB port and wait until the 'Device driver software installed Successfully' message is displayed. (Displayed only if any of the drivers are missing)
3. **Install** Dimension Two software by clicking "**D2v1.20.20 Setup.exe**"
  - Follow On-Screen Instructions – When finished "**Restart the PC**"

### IDS PEAK Software

4. **Install IDS Peak** – "**ids\_peak\_2.1.0.0.exe**" (or latest version available)
  - Follow On-Screen Wizard
  - Select Setup type as Typical Install
  - Complete the installation process and "**Restart the PC**"
5. Connect the Camera to a USB 3.0 or SS port on PC using the provided USB C to A cable
6. Saving Camera Settings
  - Open provided USB thumb drive / Settings Files folder
  - Copy settings file "**COM6067(02)\_settings\_file\_smartcam50.cset**"
  - Save the Settings file to **C:\Users\Public\Documents\MetLogix\Settings** folder
  - The file name **MUST** be renamed and saved as "**DimensionTwo-1.cset**"
7. Insert the **D2 USB Dongle** into the USB port on the PC
8. **Open** the (D2) Dimension Two software
9. **D2 Video Setup**
  - Click on the **D2** icon in the top right of the screen
  - Go to **Settings** and then **Video**
  - Select Image Source as "**PEAK**"
  - Camera Choice as "**U3-368xXLE-Cxxxxxxxx**"
  - Choose "Config File" settings as "**1**"
  - Click **Done x 2** and **CLOSE** the Software
  - **Restart** Dimension Two Software
10. Dimension Two is now installed and **ready for use**.