

Quick Install / Setup with Lynx EVO Smart Cam5A

- **Uninstall** all previous versions of Dimension One/Two software if any.
- Insert the **security dongle** into a USB port and wait until the 'Device driver software installed Successfully' message is displayed before continuing. (Only displayed if those drivers are missing)
- **Install** Dimension Two software by clicking "**D2v1.20.00Setup.exe**"
 - Follow On-Screen Instructions – When finished **Reboot PC**
- Insert the **D2 Dongle** into the USB port on the PC
- **Open** the Dimension Two software
- **Video Setup**
 - Click on the **D2** icon in the top right of the screen
 - Go to **Settings** and then **Video**
 - Select Image Source as "**DirectShow**"
 - Camera Choice as "**Basler GenICam Source**"
 - Click **Done x 2 and CLOSE** the Software
 - **Restart** Dimension Two Software
- Dimension Two is now installed and **ready for use**.