


ViCapture Software Quick Setup

Recommended System Specs: Win 7/10 – 64 bit, Intel® Core i5 - 2.5 GHz, 4GB RAM / 32 GB HD

1. **Install ViCapture** Software from provided usb drive - **ViCaptureSetup.msi**
(Do not connect the Lynx EVO Smart Cam5 HD to the computer)
 2. Follow ViCapture installation wizard until the **Installation Complete** screen is displayed
 3. **Network Properties** Settings: After installing ViCapture Successfully
 - Go to **Control Panel** (Start button and type “Control Panel.”)
 - Select **Network and Internet**
 - Select **Network and Sharing Center**
 - Select **Change Adapter Settings** (from left menu)
 - Click on your **Network**: Right Click and select **Properties**
 - Make sure “Gigabit Ethernet uEye” is **Unchecked**
 - Click **OK**
 4. **Connect** the Lynx EVO Smart Cam5 HD to the PC and then it Power ON
 5. Launch ViCapture Software - Select the required language
 6. Enter **Supervisor** mode, click the  button and enter the password (Default password: **Vision**) and click **OK**.
 7. Select **Camera** and Load Camera Settings
 - Click on the ‘**Settings Tab**’
 - **Camera** > Select the correct camera “**U358xLE-C 4xxxxxxxxx**” to activate.
 - **Settings >Manage> Import** > Select the correct .ini file
“**LynxEvoSmartCam5_CameraSettings_1v0 (APR17).ini**” > **SAVE**
- (NOTE: .ini files are on thumb drive with Mantis or Lynx EVO, in the “extras” folder
If the image is reversed, either camera settings ini file are not loaded (default settings is for Mantis), or loaded the wrong settings ini file.)
8. Lynx EVO Smart Cam5 HD is now ready for use