


IMPORTANT: Before installing software, make sure you read the instructions and follow Lynx EVO assembly steps in the User's Guide.

- 1** Unpack
- 2** Assemble Lynx EVO
- 3** Install Software

Min. Recommended System Specs:

Windows 10 (32/64-bit), Intel® Core i5 - 2.5 GHz, 4GB RAM / 200 GB HD

1. Uninstall any previous version of IDS uEye, Pylon and ViCapture software from your PC.
2. Do not plug SmartCam 50 camera into the PC
3. Install IDS Peak – “**ids_peak_2.1.0.0.exe**”
 - Follow On-Screen Wizard
 - Select Setup type as Typical
 - Complete Installation process
4. **"Restart the PC"**
5. Install ViCapture v2.1 Software from provided USB thumb drive – “**setup.exe**”
 - Complete the installation process and **“Restart the PC”**
6. Connect the SmartCam 50 camera to USB 3.0 or SS port on PC using the provided USB C to A cable
 - Launch the ViCapture v2.1 software
 - Enter Supervisor mode, click the  button and enter the password. (Default password: Vision) and click OK.
 - Load Camera and Settings

Click on the **'Settings Tab'**

Camera > From drop down select the camera “**U3-368xXLE-C xxxxxxxx**”

Settings > From drop down select the correct settings file and Save

(To import the settings file - Click on Manage> Import> open the “ settings File” folder and select the file “COM6067(02)_settings_file_smartcam50.cset” > Click on Save and Close > Open drop down in settings and select the saved settings file)
7. Lynx EVO with SmartCam50 is now ready for use

