

uEye Software Quick Setup

Minimum system requirements: Win 7 or 10 / 64-bit, Intel® Core™ i5 - 2.5 GHz,
4GB RAM / 32GB HD

1. Install uEye Cockpit Software from provided usb drive - uEye64_46000_WHQL.exe
(Do not connect the Lynx EVO SmartCam HD to the computer)
2. Connect and power on the Lynx EVO SmartCam HD to the PC
(Camera name in Device Mgr - UI-155xLE)
3. Launch uEye Cockpit.- Select **“Optimal Color”** or **“No Profile”**
(Select Expert mode if you need dimensioning or image annotation)



4. Click on the **‘Open camera’** icon to activate Lynx EVO SmartCam HD.



5. Load Camera Settings Parameters from the USB thumb drive:
 - **Go to File / Load parameters / from File....select USB drive**
 - Open folder **uEye Cockpit software** and select **“LynxEvoSmartcamHD_CameraSettings_1v2 (APR17).ini”**
6. Lynx EVO SmartCam HD is now ready for use